



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
LIST	-/--
DISPLAY	
ASPECT	
SUBTITLE	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
	BACK
SLEEP	SLEEP
DTV / ATV	TV/DTV
GUIDE	EPG

ORIGINAL	SUPERIOR
FAV	FAV
FREEZE	
HOLD	/ SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
CYAN	BLUE
MTS	SHIFT+MUTE
CANCEL	SHIFT+EXIT
MEDIA	SHIFT+6
REVEAL	SHIFT+
SIZE	SHIFT+
P. MODE	SHIFT+
S. MODE	SHIFT+
SUB.PG	SHIFT+DOWN
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
TV/RADIO	SHIFT+TV/DTV
INDEX	SHIFT+INFO
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

