



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
HDMI	/ AV
FILE LIST	-/--
ZOOM	
LANG.	
TEXT	
V+	VOL+
V-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RECALL	BACK
TV / RADIO	TV/DTV
INFO	INFO
GUIDE	EPG
FAV	FAV

ORIGINAL	SUPERIOR
AUTO	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
DEV. LIST	SHIFT+ -/--
SUBTITLE	SHIFT+
SKIP PREV.	SHIFT+ P-
SKIP NEXT	SHIFT+ P+
PAGE DOWN	SHIFT+DOWN
PAGE UP	SHIFT+UP
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

