



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
A / B	 / AV
SUBTITLE	
TEXT	
V+	VOL+
V-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RECALL	BACK
TV / 	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV
RED / F1	RED
GREEN / F2	GREEN

[illegible]