



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV/R	-/--
OPT	
	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
TV/STB	TV/DTV
INFO	INFO
EPG	EPG
MSG	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW

[illegible]