



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
MODE	-/--
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
LAST	BACK
SLEEP	SLEEP
TV/RADIO	TV/DTV
INFO	INFO
EPG	EPG
FAVOR	FAV
RED	RED
GREEN	GREEN

[illegible]