



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
TV MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
-/--	-/--
DISPLAY	
REVEAL / ZOOM	
P. MODE	
TEXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
	BACK
SLEEP	SLEEP
MEDIA	TV/DTV
INDEX	INFO

ORIGINAL	SUPERIOR
EPG	EPG
FAV	FAV
AUTO	/ NET TV
HOLD	/ SMART
RED / TV/RADIO	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
S. MODE	SHIFT+MUTE
SIZE	SHIFT+
NICAM / AUDIO	SHIFT+
SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
FAV+	SHIFT+UP
FAV -	SHIFT+DOWN
STOP / SUBPAGE	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

