ORIGINAL	SUPERIOR
STANDBY/ON	POWER
MUTE	MUTE
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
FOLDER	/ SOURCE
>10	-/--
DISPLAY	
EQUALIZER MODE	
BASS/TREBLE	
CLOCK/TIMER	
VOL+	VOL+
VOL -	VOL -
REW / SKIP NEXT / TUN+	P+
FWD / SKIP PREV / TUN -	P -
UP / PRESET+	UP
DOWN / PRESET -	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
SLEEP	SLEEP
PLAY MODE	TV/DTV
DIMMER	INFO
MEMORY	EPG
EXTRA BASS	FAV

ORIGINAL	SUPERIOR
OPEN/CLOSE	/ NET TV
CD STOP	/ SMART
CD PLAY/PAUSE	YELLOW
IPOD MENU	SHIFT+MENU
INPUT AUDIO LINE	SHIFT+1
CD	SHIFT+2
IPOD/IPHONE	SHIFT+3
TUNER (BAND)	SHIFT+4
USB	SHIFT+5
IPOD DISPLAY	SHIFT+
RDS ASPM	SHIFT+
RDS PTY	SHIFT+
RDS DISPLAY	SHIFT+
IPOD PLAY/PAUSE	SHIFT+YELLOW