ORIGINAL	SUPERIOR
POWER	POWER
🔇	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
LIST	-/--
DISP.	▭
OPT.	⊟
TEXT	▤
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
TV / ♪	TV/DTV
INFO	INFO
EPG	EPG
APP	FAV
PLAY/PAUSE	⏸ / SMART TUBE

ORIGINAL	SUPERIOR
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE