ORIGINAL	SUPERIOR
DVD	
POWER	POWER
AUDIO	MUTE
DISC MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DVD	/ SOURCE
RANDOM	-/--
DISPLAY	
ZOOM	
SETUP	
SUBTITLE	
A – B	P+
REPEAT	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
ANGLE	SLEEP
TOP MENU	TV/DTV
SEARCH	INFO

ORIGINAL	SUPERIOR
PROGRAM	EPG
MARK	FAV
OPEN/CLOSE	/ NET TV
PAUSE/STEP	/ SMART TUBE
STOP	/ SMART VIDEO
REW/SKIP PREV	GREEN
PLAY	YELLOW
FWD/SKIP NEXT	BLUE
VCR	
POWER	SHIFT+POWER
AUDIO	SHIFT+MUTE
CLEAR	SHIFT+EXIT
1/2/3/4/5	SHIFT+1/2/3/4/5
6/7/8/9/0	SHIFT+6/7/8/9/0
AV	SHIFT+
VCR	SHIFT+ -/--
SHOWVIEW	SHIFT+
C. LOCK	SHIFT+
AD-SKIP	SHIFT+
SEARCH	SHIFT+
DOWN/CH/TRACK -	SHIFT+DOWN
UP /CH/TRACK+	SHIFT+UP
LEFT	SHIFT+LEFT
RIGHT	SHIFT+RIGHT

ORIGINAL	SUPERIOR
OK	SHIFT+OK
REPEAT	SHIFT+BACI
CLK./CNT.	SHIFT+SLEE
TV/VCR	SHIFT+ TV/D
I	SHIFT+INFC
OUTPUT SELECT	SHIFT+EPG
SPEED	SHIFT+FAV
EJECT	SHIFT+
PAUSE/STEP	SHIFT+
STOP	SHIFT+
REC/OTR.	SHIFT+RED
REW	SHIFT+GREE
PLAY	SHIFT+YELLO
FWD	SHIFT+BLUI