ORIGINAL	SUPERIOR
POWER	POWER
MUTING	MUTE
AUX	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0-10	6/7/8/9/0
FUNCTION	/ SOURCE
>10	-/--
VOLUME+	VOL+
VOLUME -	VOL -
UP	UP
DOWN	DOWN
REW/SKIP PREV	LEFT
FWD/SKIP NEXT	RIGHT
ENTER	OK
REPEAT	BACK
SLEEP	SLEEP
TAPE PLAY/PLAY REV.	TV/DTV
CLOCK	INFO
SHUFFLE/PROGRAM	EPG
TUNER/BAND	FAV
STOP	/ SMART
CD PLAY/PAUSE	YELLOW
TIMER	SHIFT+POWER

ORIGINAL	SUPERIOR