ORIGINAL	REPLACEMENT
POWER	POWER
MUTE	MUTE
/ HOME	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
HDMI/AV	/ SOURCE
COPY	-/--
EDIT	
SETUP	
TTX	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT/PG UP	P+
SKIP PREV/PG DN	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
REPEAT	BACK
TIMER	SLEEP
DTV	TV/DTV
INFO	INFO
EPG	EPG

ORIGINAL	REPLACEMENT
FAV	FAV
DISK	/ NET TV
PAUSE	/ SMART TUBE
STOP	/ SMART VIDEO
REC.	RED
REV.	GREEN
PLAY	YELLOW
F.F.	BLUE
AUDIO	SHIFT+MUTE
/ MOVIE	SHIFT+1
/ MUSIC	SHIFT+2
/ PHOTO	SHIFT+3
DVD	SHIFT+
T/R	SHIFT+ -/--
SUB – T	SHIFT+