ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
EPG	EPG
FAV	FAV
RED/TV-R	RED
GREEN/SUB	GREEN
YELLOW/TTX	YELLOW
BLUE/INFO	BLUE
AUDIO	SHIFT+MUTE
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
STOP	SHIFT+ ■
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

ORIGINAL	SUPERIOR