ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ SOURCE	/ SOURCE
LIST	-/--
▶|◀	
FORMAT	
MEDIA	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
TIMER/DEL	SLEEP
RADIO	TV/DTV
i+	INFO

ORIGINAL	SUPERIOR
GUIDE	EPG
?	FAV
RED/A – Z	RED
GREEN/LANG	GREEN
YELLOW/S – TITLE	YELLOW
BLUE/A.FOCUS	BLUE
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
STOP	SHIFT+ ■
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE