| ORIGINAL | SUPERIOR |
|---|---|
| ON/OFF | POWER |
| MUTE | MUTE |
| MENU | MENU |
| EXIT | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| SHUFFLE | -/-- |
| SETUP | |
| PLAYLIST | |
| VOL+ | VOL+ |
| VOL - | VOL - |
| NEXT TRACK | P+ |
| PREV TRACK | P - |
| UP | UP |
| DOWN | DOWN |
| LEFT | LEFT |
| RIGHT | RIGHT |
| OK | OK |
| REPEAT | BACK |
| INFO | INFO |
| GUIDE | EPG |
| LIBRARY | FAV |
| PAUSE | |
| STOP | / SMART |
| REW | GREEN |

| ORIGINAL | SUPERIOR |
|---|---|
| PLAY | YELLOW |
| FWD | BLUE |
| SYSTEM | SHIFT+MENU |
| AM RADIO | SHIFT+1 |
| AUX | SHIFT+2 |
| CBL / SAT | SHIFT+3 |
| CD / DVD | SHIFT+4 |
| FM RADIO | SHIFT+5 |
| TV | SHIFT+6 |
| VCR | SHIFT+7 |
| RATING+ | SHIFT+ P+ |
| RATING - | SHIFT+ P - |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |