ORIGINAL	SUPERIOR
•	POWER
🔇	MUTE
PROCESS	MENU
CLEAR/RECORD	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE 2	/ SOURCE
SPEAKER	-/--
GOTO/MEMO	
>|<	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT/RESET	P+
SKIP PREV/SET	P -
TREBLE	UP
BASS	DOWN
BALANCE -	LEFT
BALANCE+	RIGHT
SET/A. SPACE	OK
LOUDN.	SLEEP
MONO	TV/DTV
CONTROL	EPG
PAUSE/LIFT	/ SMART TUBE
STOP	/ SMART VIDEO
REW	GREEN

ORIGINAL	SUPERIOR
START/STOP	YELLOW
FWD	BLUE
CD	SHIFT+1
PHONO	SHIFT+2
FM	SHIFT+3
TV	SHIFT+4
TAPE	SHIFT+5