ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
MENU	MENU
SNOOZE	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
CLOCK	-/--
MODE	
EQ	
SCAN	
PRESET	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP / PLAY/PAUSE	UP
DOWN	DOWN
PRESET/FOLDER -	LEFT
PRESET/FOLDER+	RIGHT
SELECT	OK
BACK	BACK
SLEEP	SLEEP
MONO/ST.	TV/DTV
INFO	INFO
ALARM	EPG

ORIGINAL	SUPERIOR
---	SHIFT+1
---	SHIFT+2
---	SHIFT+3
---	SHIFT+4