ORIGINAL	SUPERIOR
AMPLIFIER POWER	POWER
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
+10	-/--
CALL	
TITLE/ARTIST	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
REPEAT	BACK
TIME	SLEEP
MODE SELECT	TV/DTV
DIMMER	INFO
DISC LAYER	EPG
PLAY SELECT	FAV
RESTORER	/ NET TV
PAUSE	
STOP	/ SMART
REW	GREEN

ORIGINAL	SUPERIOR
PLAY	YELLOW
FWD	BLUE