ORIGINAL	SUPERIOR
ON / STANDBY	POWER
MUTE	MUTE
MENU	MENU
CLEAR / DEL.	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
+10	-/--
TIME / DISPLAY	
REMOTE / BROWSE	
DAB / RDS	
FOLDER MODE	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT / CH+	P+
SKIP PREV / CH -	P -
UP / FOLDER+	UP
DOWN / FOLDER -	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER / MEMO.	OK
REPEAT	BACK
SLEEP	SLEEP
TUNER	TV/DTV
DIMMER	INFO

ORIGINAL	SUPERIOR
PROG. / DIRECT	EPG
RANDOM	FAV
USB/iPod PLAY/PAUSE	
STOP	/ SMART
REW / TU -	GREEN
CD PLAY/PAUSE	YELLOW
FWD / TU+	BLUE
CLOCK	SHIFT+SLEEP
SDB / TONE	SHIFT+EPG
DOCK PLAY/PAUSE	SHIFT+YELLOW