ORIGINAL	SUPERIOR
ON/STANDBY	POWER
MUTE	MUTE
MENU / GUIDE	MENU
AUX	1
DVD	2
TUNER	3
VOLUME+	VOL+
VOLUME -	VOL -
SKIP / TUNING+	P+
SKIP / TUNING -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
PUSH / ENTER	OK
RETURN	BACK
SLEEP	SLEEP
STEREO / MUSIC	TV/DTV
HELP	INFO
STILL / PAUSE	⏸
STOP / BAND	■ / SMART
SLOW/SEARCH REW	GREEN
PLAY	YELLOW
SLOW / SEARCH FWD	BLUE
CHANNEL+	SHIFT+ P+

ORIGINAL	SUPERIOR
CHANNEL -	SHIFT+ P -