ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
SDB TONE	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
+10	-/--
CLOCK	
RENOTE/BROWSE	
SETUP	
RANDOM	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
REPEAT	BACK
SLEEP	SLEEP
DAB/RDS	TV/DTV
INFO	INFO
PROGRAM	EPG

ORIGINAL	SUPERIOR
FOLDER MODE	FAV
STOP	■ / SMART
REW	GREEN
PLAY/PAUSE	YELLOW
FWD	BLUE
ANALOG IN	SHIFT+1
CD	SHIFT+2
DIGITAL IN	SHIFT+3
TUNER	SHFIT+4
USB	SHIFT+5
CHANNEL+	SHIFT+ P+
CHANNEL -	SHIFT+ P -
DIMMER	SHIFT+INFO