ORIGINAL	SUPERIOR
POWER	POWER
🔇	MUTE
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
+10	-/--
CLOCK	▭
DIMMER	☀
VOLUME+	VOL+
VOLUEM -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
BACK	BACK
SLEEP	SLEEP
SHUFFLE	TV/DTV
INFO	INFO
REPEAT	FAV
STOP	■ / SMART
REW/TUNE -	GREEN
PLAY/PAUSE	YELLOW

ORIGINAL	SUPERIOR
FWD/TUNE -	BLUE
AM	SHIFT+1
ANALOG IN	SHIFT+2
BLUETOOTH	SHIFT+3
CD	SHIFT+4
FM	SHIFT+5
OPTICAL IN	SHIFT+6