ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
MENU	MENU
ECO	EXIT
BLUETOOTH	1
BLUE RAY	2
CBL – SAT	3
CD	4
DVD	5
GAME	6
INTERNET RADIO	7
MEDIA PLAYER	8
PHONO	9
TUNER	0
TV / RADIO	/ SOURCE
USB	-/--
SETUP	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT

ORIGINAL	SUPERIOR
ENTER	OK
BACK	BACK
SLEEP	SLEEP
SPEAKER	TV/DTV
INFO	INFO
PLAY / PAUSE	YELLOW
QUICK SELECT 1	SHIFT+1
QUICK SELECT 2	SHIFT+2
QUICK SELECT 3	SHIFT+3
QUICK SELECT 4	SHIFT+4
TUNE+	SHIFT+ P+
TUNE -	SHIFT+ P -
CH / PAGE+	SHIFT+UP
CH / PAGE -	SHIFT+DOWN