ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TXT	▤
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
↩	BACK
INFO	INFO
EPG	EPG
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
SUBT	SHIFT+▤
⏫	SHIFT+UP
⏬	SHIFT+DOWN

ORIGINAL	SUPERIOR
PAUSE	SHIFT+⏸
STOP	SHIFT+■
REC	SHIFT+RED
PLAY / PAUSE	SHIFT+YELLOW