ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
▲ P	P+
▼ P	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
↩ / BACK	BACK
TV/R	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV
RED/TXT	RED
GREEN/AUDIO	GREEN
YELLOW/ASPECT	YELLOW
BLUE/SUB – T	BLUE
STOP	SHIFT+ ■
REW	SHIFT+GREEN
PLAY/PAUSE	SHFIT+YELLOW

ORIGINAL	SUPERIOR
FWD	SHIFT+BLUE