ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
USB	/ SOURCE
FIND	-/--
TV FORMAT	
OPTION	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK/ENTER	OK
RECALL	BACK
STATUS	SLEEP
TV/R	TV/DTV
i	INFO
EPG	EPG
FAV	FAV

ORIGINAL	SUPERIOR
RED/AUDIO	RED
GREEN/SUBTITLE	GREEN
YELLOW/SLEEP	YELLOW
BLUE/TEXT	BLUE
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
STEP	SHIFT+SLEEP
STOP	SHIFT+ ■
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE