ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
/ EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DTV / VCR	/ SOURCE
PVR – LIST	-/--
GO TO	
TTX	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RECALL	BACK
TV / RADIO	TV/DTV
INFO	INFO
EPG	EPG
FAVOURITE	FAV
RED / ZOOM	RED

ORIGINAL	SUPERIOR
GREEN /	GREEN
YELLOW /	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
SUBTITLE	SHIFT+
SKIP PREV	SHIFT+ P -
SKIP NEXT	SHIFT+ P+
RPT.	SHIFT+BACK
PAUSE	SHIFT+
STOP	SHIFT+
PVR – REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE