ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
MENU	MENU
SEARCH	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
USB	/ SOURCE
+10	-/--
OSD	
ZOOM	
SETUP	
SUBTITLE	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT/F.R.	LEFT
RIGHT/F.F.	RIGHT
OK	OK
REPEAT	BACK
AUDIO	SLEEP
HDMI	TV/DTV
TITLE	INFO

ORIGINAL	SUPERIOR
3D	EPG
CHANNEL	FAV
EJECT	/ NET TV
STOP	/ SMART VIDEO
PLAY/PAUSE	YELLOW
BROWSE	SHIFT+MENU
ANGLE	SHIFT+EXIT