| ORIGINAL | SUPERIOR |
|---|---|
| ⏻ | POWER |
| 🔇 | MUTE |
| MENU | MENU |
| EXIT | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| UP | UP |
| DOWN | DOWN |
| LEFT | LEFT |
| RIGHT | RIGHT |
| OK | OK |
| BACK | BACK |
| TV / R | TV/DTV |
| INFO | INFO |
| FAV | FAV |
| RED / EPG | RED |
| GREEN / AUDIO | GREEN |
| YELLOW / SUB | YELLOW |
| BLUE / ZOOM | BLUE |
| SKIP NEXT | SHIFT+ P+ |
| SKIP PREV | SHIFT+ P - |
| STOP | SHIFT+ ■ |
| REC | SHIFT+RED |
| REW | SHIFT+GREEN |
| PLAY / PAUSE | SHIFT+YELLOW |

| ORIGINAL | SUPERIOR |
|---|---|
| FWD | SHIFT+BLUE |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |