ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TIMER ON/OFF	-/--
RDS / DISPLAY	▭
VOLUME UP	VOL+
VOLUME DOWN	VOL -
P. CALL+	P+
P. CALL -	P -
SKIP PREV. / TUNING-	LEFT
SKIP NEXT / TUNING+	RIGHT
ENTER	OK
REPEAT	BACK
SLEEP	SLEEP
EQ. / X-BASS	TV/DTV
PROGRAM	EPG
RANDOM	FAV
STOP	■ / SMART
SEARCH REW	GREEN
PLAY	YELLOW
SEARCH FWD	BLUE
CD	SHIFT+1
TAPE / MODE	SHIFT+2
TUNER / BAND / USB	SHIFT+3

ORIGINAL	SUPERIOR