ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
AUX	1
CD	2
PHONO	3
TAPE A	4
TAPE B	5
TUNER	6
TUNER – BAND	-/--
VOLUME+	VOL+
VOLUME-	VOL-
CD – SKIP NEXT	P+
CD – SKIP PREV.	P-
TAPE A – PLAY REV.	LEFT
CD – PLAY/PAUSE	RIGHT
CD – STOP	OK
SLEEP	SLEEP
TAPE A – STOP	■
TAPE A – REW	GREEN
TAPE A – PLAY	YELLOW
TAPE A – FWD	BLUE
TAPE B – PLAY REV.	SHIFT+LEFT
TAPE B – PAUSE	SHIFT+ II
TAPE B – STOP	SHIFT+ ■
TAPE B – REC	SHIFT+RED

ORIGINAL	SUPERIOR
TAPE B – REW	SHIFT+GREEN
TAPE B – PLAY	SHIFT+YELLOW
TAPE B – FWD	SHIFT+BLUE