ORIGINAL	SUPERIOR
POWER	POWER
/ AUDIO	MUTE
DISC MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
*	/ SOURCE
DVD	-/--
DISPLAY	
ZOOM	
SETUP	
/ SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK / ENTER	OK
/ RETURN	BACK
/ ANGLE	SLEEP
RANDOM / CM SKIP	TV/DTV
TITLE	INFO
PROGRAM	EPG
MARKER	FAV

ORIGINAL	SUPERIOR
EJECT / OPEN/CLOSE	/ NET TV
PAUSE	
STOP	/ SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
SEARCH	SHIFT+EXIT
REPEAT	SHIFT+BACK
A – B / LP	SHIFT+SLEEP