ORIGINAL	SUPERIOR
POWER	POWER
/ AUDIO	MUTE
/ HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ SEARCH	-/--
DISPLAY	
ZOOM	
SUBTITLE ON/OFF	
/ SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
/ RETURN	BACK
DISC MENU	TV/DTV
TITLE / POP – UP	INFO
RESOLUTION	EPG
MARKER	FAV
OPEN / CLOSE	/ NET TV
PAUSE	

ORIGINAL	SUPERIOR
STOP	/ SMART
SCAN REW	GREEN
PLAY	YELLOW
SCAN FWD	BLUE
REPEAT	SHIFT+BACK
RED / A	SHIFT+RED
GREEN / B	SHIFT+GREEN
YELLOW / C	SHIFT+YELLOW
BLUE / D	SHIFT+BLUE