ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
DISC MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ RADIO&INPUT	/ SOURCE
OPTICAL	-/--
HOME	
SOUND EFFECT	
SPEAKER LEVEL	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP/PRESET+	UP
DOWN/PRESET -	DOWN
LEFT/TUNING -	LEFT
RIGHT/TUNING+	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP
MUSIC ID	TV/DTV
INFO/DISPLAY	INFO
TITLE/POPUP	EPG

ORIGINAL	SUPERIOR
MARKER	FAV
OPEN/CLOSE	/ NET TV
PAUSE	/ SMART TUBE
STOP	/ SMART VIDEO
REC	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE
SEARCH	SHIFT+EXIT
REPEAT	SHIFT+BACK
RED	SHIFT+RED
GREEN	SHIFT+GREEN
YELLOW	SHIFT+YELLOW
BLUE/MONO-STEREO	SHIFT+BLUE