ORIGINAL	SUPERIOR
POWER	POWER
/ HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SEARCH	-/--
DISPLAY / INFO	
ZOOM	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
/ RETURN	BACK
MUSIC ID	SLEEP
DISC MENU	TV/DTV
TITLE / POPUP	INFO
MARKER	FAV
OPEN / CLOSE	/ NET TV
PAUSE	
STOP	/ SMART
REW	GREEN
PLAY	YELLOW

ORIGINAL	SUPERIOR
FWD	BLUE
/ REPEAT	SHIFT+BACK
RED	SHIFT+RED
GREEN	SHIFT+GREEN
YELLOW	SHIFT+YELLOW
BLUE	SHIFT+BLUE