ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
DISC MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ FUNCTION	/ SOURCE
TITLE/POPUP	-/--
/ HOME	
SOUND EFFECT	
SPEAKER LEVEL	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP/PRESET+	UP
DOWN/PRESET -	DOWN
LEFT/TUNING -	LEFT
RIGHT/TUNING+	RIGHT
ENTER	OK
/ REPEAT	BACK
SLEEP	SLEEP
INFO/MENU	INFO
OPEN/CLOSE	/ NET TV

ORIGINAL	SUPERIOR
PAUSE/STEP	/ SMART TUBE
STOP	/ SMART VIDEO
REC	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE
AUDIO	SHIFT+MUTE
RED	SHIFT+RED
GREEN	SHIFT+GREEN
YELLOW	SHIFT+YELLOW
BLUE / MONO/STEREO	SHIFT+BLUE