ORIGINAL	SUPERIOR
DVD	
POWER	POWER
AUDIO	MUTE
DISC MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DVD	/ SOURCE
SEARCH	-/--
DISPLAY	
ZOOM	
SETUP	
SUBTITLE	
A – B	P+
REPEAT	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK / ENTER / SELECT	OK
RETURN	BACK
RANDOM	SLEEP
ANGLE	TV/DTV
TITLE	INFO

ORIGINAL	SUPERIOR
PROGRAM	EPG
MARKER	FAV
OPEN / CLOSE	/ NET TV
PAUSE / STEP	
STOP	/ SMART
BACKWARD / SKIP PR.	GREEN
PLAY	YELLOW
FORWARD / SKIP NEX.	BLUE
VCR	
POWER	SHIFT+POWER
AUDIO	SHIFT+MUTE
CLEAR	SHIFT+EXIT
1/2/3/4/5	SHIFT+ 1/2/3/4/5
6/7/8/9/0	SHIFT+ 6/7/8/9/0
AV	SHIFT+
VHS	SHIFT+ -/--
CLK. / CNT.	SHIFT+
C. LOCK	SHIFT+
i	SHIFT+
SEARCH	SHIFT+
LP	SHIFT+ P+
ez. REPLAY / REPEAT	SHIFT+ P -
DOWN	SHIFT+DOWN
UP	SHIFT+UP

ORIGINAL	SUPERIOR
LEFT	SHIFT+LEF
RIGHT	SHIFT+RIGH
OK / ENTER / SELECT	SHIFT+OK
CM SKIP	SHIFT+SLEE
TV / VCR	SHIFT+ TV/D
OUTPUT SELECT	SHIFT+FAV
EJECT	SHIFT+
PAUSE / STEP	SHIFT+
STOP	SHIFT+
REC / ITR.	SHIFT+REI
BACKWARD / SKIP PR.	SHIFT+GREE
PLAY	SHIFT+YELL
FORWARD / SKIP NEX.	SHIFT+BLU