| ORIGINAL | SUPERIOR |
|---|---|
| POWER | POWER |
| MUTE | MUTE |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| FUNCTION | / SOURCE |
| DISP. MODE | |
| DIMMER | |
| RDS | |
| EQ. MASTER | |
| VOLUME ︿ | VOL+ |
| VOLUME ﹀ | VOL - |
| PRESET/FOLDER ︿ | P+ |
| PRESET/FOLDER ﹀ | P - |
| UP | UP |
| DOWN/REPEAT | DOWN |
| LEFT/TUNING - | LEFT |
| RIGHT/TUNING+ | RIGHT |
| OK / MO./ST. | OK |
| SLEEP | SLEEP |
| XDSS PLUS | TV/DTV |
| INFO | INFO |
| PROGRAM / MEMORY | EPG |
| XTS PRO. | FAV |
| STOP | / SMART VIDEO |
| REW/SKIP PREV | GREEN |

| ORIGINAL | SUPERIOR |
|---|---|
| PLAY/PAUSE | YELLOW |
| FWD/SKIP NEXT | BLUE |
| CLOCK | SHIFT+SLEEP |
| PTY. | SHIFT+ TV/DTV |
| PTY. SEARCH | SHIFT+FAV |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |