ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
/ HOME	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
RADIO / INPUT	/ SOURCE
OPTICAL	-/--
INFO / DISPLAY	
SOUND EFFECT	
SPEAKER LEVEL	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP / PRESET+	UP
DOWN / PRESET -	DOWN
LEFT / TUNING -	LEFT
RIGHT / TUNING+	RIGHT
ENTER	OK
/ REPEAT	BACK
SLEEP	SLEEP
SEARCH	TV/DTV
TITLE / POPUP	INFO
DISC MENU	EPG

ORIGINAL	SUPERIOR
MARKER	FAV
OPEN / CLOSE	/ NET TV
PAUSE / STEP	
STOP	/ SMART
REC	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE
RED / RDS	SHIFT+RED
GREEN / PTY	SHIFT+GREEN
YELLOW / PTY SEARCH	SHIFT+YELLOW
BLUE / MONO/STEREO	SHIFT+BLUE