| ORIGINAL | SUPERIOR |
|---|---|
| POWER | POWER |
| MUTE | MUTE |
| OPTIONS | MENU |
| CLEAR | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| +10 | -/-- |
| CLOCK | |
| SPEAKER A/B | |
| SETUP | |
| VOLUME A/B | |
| VOLUME+ | VOL+ |
| VOLUME - | VOL - |
| SKIP NEXT | P+ |
| SKIP PREV | P - |
| UP | UP |
| DOWN | DOWN |
| LEFT | LEFT |
| RIGHT | RIGHT |
| ENTER | OK |
| / REPEAT | BACK |
| SLEEP | SLEEP |
| DBB/TONE | TV/DTV |
| INFO | INFO |
| PROGRAM | EPG |

| ORIGINAL | SUPERIOR |
|---|---|
| / RANDOM | FAV |
| OPEN/CLOSE | / NET TV |
| STOP | / SMART |
| PLAY/PAUSE | YELLOW |
| SEARCH | SHIFT+EXIT |
| CD | SHIFT+1 |
| USB | SHIFT+2 |
| BLUETOOTH | SHIFT+3 |
| TUNER | SHIFT+4 |
| ANNLOG IN | SHIFT+5 |
| OPTICAL IN | SHIFT+6 |
| CHANNEL+ | SHIFT+ P+ |
| CHANNEL - | SHIFT+ P - |
| DIMMER | SHIFT+INFO |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |