| ORIGINAL | SUPERIOR |
|---|---|
| AMP POWER | POWER |
| MUTE | MUTE |
| OPTION | MENU |
| CLEAR | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| INPUT | / SOURCE |
| +10 | -/-- |
| QUEUE | |
| DIMMER | |
| SETUP | |
| / RANDOM | |
| VOL+ | VOL+ |
| VOL - | VOL - |
| SKIP NEXT | P+ |
| SKIP PREV | P - |
| UP | UP |
| DOWN | DOWN |
| LEFT | LEFT |
| RIGHT | RIGHT |
| ENTER | OK |
| BACK | BACK |
| SLEEP | SLEEP |
| FAV ADD | TV/DTV |
| INFO | INFO |

| ORIGINAL | SUPERIOR |
|---|---|
| SOURCE DIRECT | EPG |
| FAV CALL | FAV |
| STOP | / SMART |
| PLAY/PAUSE | YELLOW |
| CD POWER | SHIFT+POWER |
| INTERNET RADIO | SHIFT+1 |
| USB | SHIFT+2 |
| MUSIC SERVERS | SHIFT+3 |
| AUX | SHIFT+4 |
| RECORDER | SHIFT+5 |
| OPT/COAX | SHIFT+6 |
| BLUETOOTH | SHIFT+7 |
| PHONO | SHIFT+8 |
| / REPEAT | SHIFT+BACK |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |