ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
OPTIONS	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
+10	-/--
CLOCK	
SPEAKER A/B	
SETUP	
VOLUME A/B	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
/ REPEAT	BACK
SLEEP	SLEEP
DBB/TONE	TV/DTV
INFO	INFO
PROGRAM	EPG

ORIGINAL	SUPERIOR
/ RANDOM	FAV
OPEN/CLOSE	/ NET TV
STOP	/ SMART
PLAY/PAUSE	YELLOW
SEARCH	SHIFT+EXIT
CD	SHIFT+1
USB	SHIFT+2
BLUETOOTH	SHIFT+3
TUNER	SHIFT+4
ANNLOG IN	SHIFT+5
OPTICAL IN	SHIFT+6
CHANNEL+	SHIFT+ P+
CHANNEL -	SHIFT+ P -
DIMMER	SHIFT+INFO