ORIGINAL	SUPERIOR
⏻	POWER
MENU	MENU
	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
HOME	▭
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
INFO	INFO
MY TV	FAV
REC	RED
REW	GREEN
PLAY/PAUSE	YELLOW
FWD	BLUE
SKIP NEXT / PG UP	SHIFT+ P+
SKIP PREV / PG DOWN	SHIFT+ P -
STOP	SHIFT+ ■
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

ORIGINAL	SUPERIOR