ORIGINAL	SUPERIOR
	MUTE
PIP	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
MODE	/ SOURCE
2nd AUDIO	-/--
DISPLAY	
GOTO	
SETUP	
SUB – T	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
SLOW	SLEEP
MEDIA CENTER	TV/DTV
TITLE POPUP	INFO
OSC	EPG

ORIGINAL	SUPERIOR
TOP MENU	FAV
STOP	/ SMART VIDEO
REW	GREEN
PLAY/PAUSE	YELLOW
FWD	BLUE
AUDIO	SHIFT+MUTE
REPEAT	SHIFT+BACK
A – B	SHIFT+SLEEP
RED/PRGM	SHIFT+RED
GREEN/MARK VIEW	SHIFT+GREEN
YELLOW/MARK SET	SHIFT+YELLOW
BLUE/ZOOM	SHIFT+BLUE