ORIGINAL	SUPERIOR
POWER – ON	POWER
AV-MUTE	MUTE
MENU	MENU
EXIT	EXIT
1 / COMPUTER 1	1
2 / COMPUTER 2	2
3 / COMPUTER 3	3
4 / VIDEO	4
5 / S-VIDEO	5
6 / HDMI	6
7/8/9/0	7/8/9/0
MOUSE – L-CLICK	/ SOURCE
MOUSE – R-CLICK	-/--
PICTURE	
AUTO ADJ.	
NUM / +	
ECO	
VOL+	VOL+
VOL -	VOL -
PAGE UP	P+
PAGE DOWN	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT

ORIGINAL	SUPERIOR
ENTER	OK
CLEAR	BACK
HELP	INFO
KEYSTONE	EPG
ASPECT	/ NET TV
FREEZE	/ SMART
POWER – OFF	SHIFT+POWER
D-ZOOM -	SHIFT+DOWN
D-ZOOM +	SHIFT+UP