ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
GO TO	-/--
OSD	
ZOOM	
ANGLE	
SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
REMAIN	INFO
PROGRAM	EPG
SHUFFLE	FAV
EJECT	/ NET TV
PAUSE	
STOP	/ SMART

ORIGINAL	SUPERIOR
REW	GREEN
PLAY	YELLOW
FWD	BLUE
AUDIO	SHIFT+MUTE
SETUP	SHIFT+MENU
SLOW	SHIFT+LEFT
REPEAT	SHIFT+BACK
REPEAT A – B	SHIFT+SLEEP