ORIGINAL	SUPERIOR
⏻	POWER
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SHOWVIEW	▭
SP / LP	⊞
SLOW	⊟
NEXT	VOL+
PREV	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
TIMER	SLEEP
TV / VCR	TV/DTV
⊡	INFO
PAUSE	⏸ / SMART TUBE
STOP	■ / SMART VIDEO
REC	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR