ORIGINAL	SUPERIOR
ON/STANDBY	POWER
POP UP/MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
... / HOME	-/--
DISPLAY	
ZOOM	
RESOLUTION	
TOP MENU	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
... / RETURN	BACK
SEARCH	INFO
MARKER	FAV
OPEN/CLOSE	/ NET TV
PAUSE	
STOP	/ SMART
REW	GREEN
PLAY	YELLOW

ORIGINAL	SUPERIOR
FWD	BLUE
REPEAT	SHIFT+BACK
RED / A	SHIFT+RED
GREEN / B	SHIFT+GREEN
YELLOW / C	SHIFT+YELLOW
BLUE / D	SHIFT+BLUE