ORIGINAL	SUPERIOR
CLR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0-10	6/7/8/9/0
>10	-/--
DISPLAY	
SETUP	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
REPEAT	BACK
DIMMER	TV/DTV
SEARCH	INFO
PLAY MODE	FAV
EJECT	/ NET TV
PAUSE	
STOP	/ SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR