ORIGINAL	SUPERIOR
ON/STANDBY	POWER
AUDIO	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TOP MENU	-/--
DISPLAY	
ZOOM	
SETUP	
SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
RESOLUTION	SLEEP
RANDOM	TV/DTV
ANGLE	INFO
PROGRAM	EPG
MARKER	FAV
OPEN/CLOSE	/ NET TV

ORIGINAL	SUPERIOR
PAUSE	/ SMART TUBE
STOP	/ SMART VIDEO
REW	GREEN
PLAY	YELLOW
FWD	BLUE
SEARCH	SHIFT+EXIT
REPEAT	SHIFT+BACK
A – B	SHIFT+FAV