| ORIGINAL | SUPERIOR |
|---|---|
| STANDBY / ON | POWER |
| MUTING | MUTE |
| MENU / NO / CLEAR | MENU |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| INPUT NEXT | / SOURCE |
| >10 | -/-- |
| DISPLAY | |
| TONE | |
| FOLDER | |
| SUPER BASS | |
| VOLUME+ | VOL+ |
| VOLUME - | VOL - |
| SKIP/PRESET NEXT | P+ |
| SKIP/PRESET PREV | P - |
| TAPE PAUSE | LEFT |
| TAPE STOP | RIGHT |
| TAPE PLAY | OK |
| REPEAT | BACK |
| SLEEP | SLEEP |
| CLOCK CALL | TV/DTV |
| YES / MODE / SHUFFLE | INFO |
| TIMER | EPG |
| TUNER BAND | FAV |
| CD PAUSE | / SMART TUBE |

| ORIGINAL | SUPERIOR |
|---|---|
| CD STOP | / SMART VIDEO |
| CD REW / TUNE DOWN | GREEN |
| CD FWD / TUNE UP | BLUE |
| CD PLAY | YELLOW |
| INPUT PREV | SHIFT+AV |
| DOCK/CDR PAUSE | SHIFT+ |
| DOCK/CDR STOP | SHIFT+ |
| DOCK/CDR PLAY | SHIFT+YELLOW |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |